

1. On top of the unit, screw-in, and hand tighten the decompression chamber. Do NOT use a wrench.
2. Remove the front panel using a flat blade screwdriver, turning the screws counterclockwise ¼ turn.
3. Position the SMART-PAK cartridge inside the cabinet with the label facing forward.
4. Attach the ¼" clear vent hose from the top inside of the cabinet, into the push-to-lock fitting on the SMART-PAK cartridge. **Failure to connect will cause oil to leak inside the cabinet.**
5. Connect the female fitting of the discharge hose to the male fitting on the inside right of the cabinet.
6. Connect the male fitting of the inlet hose to the female fitting on the inside top right of the cabinet.
7. Attach the battery-pack wire* (zip-tied to inlet hose) to the fitting on the inside top left of the cabinet. **Failure to connect the wire will prevent the unit from operating.**
8. Copy serial number from SMART-PAK cartridge to use in final step. Reattach front panel.
9. Cut the attached ¾" drain hose on the outside right of the unit to size. Do not allow airlocks, kinks, or excess coil in the drain hose. The hose MUST lay flat or unit will not drain.
10. On top of the unit remove red cap(s), replace it with push-to-lock fitting and connect ¼" condensate line from the compressor.
11. Scan QR code to complete warranty registration.

Questions?

Contact your Distributor or Clean Resources:

- 800-566-0402
- cleanresources.com/contact

- ✓ Check for damage that may have occurred during shipping
- ✓ Avoid damage to couplings
- ✓ Do not over tighten fittings

* When plugging in or unplugging the battery-pack, wait 20 seconds to allow the capacitor to completely charge/discharge.



Re-Order Parts

| Part Number | Description |
|-------------|------------------------------|
| B20041 | OUTLET HOSE ASSEMBLY |
| B21000 | INLET HUB FOR CABINET SYSTEM |
| B24000 | DECOMPRESSION CHAMBER |
| F10410 | CARTRIDGE FOR 300 |
| F10411 | CARTRIDGE FOR 600 |
| F10412 | CARTRIDGES FOR 800 |
| F10413 | CARTRIDGES FOR 1000 |
| F10414 | CARTRIDGES FOR 1500 |

Life Span

| SMART-PAK | CFM | Cartridge Life Span (Months [†]) |
|-----------|-----|--|
| 300 | 300 | 12 |
| 600 | 600 | 12 |

[†] See complete lifespan chart for details:
cleanresources.com/product.html#SMARTseries

**WARRANTY
REGISTRATION**



1. On top of the unit, screw-in, and hand tighten the decompression chamber. Do NOT use a wrench.
2. Remove the front panel using a flat blade screwdriver, turning the screws counterclockwise ¼ turn.
3. Position SMART-PAK Cartridge A on the left-inside of cabinet and SMART-PAK Cartridge B on the right with both labels facing forward.
4. Attach the short end of the ¼" vent hose from the top inside of the cabinet into the push-to-lock fitting on SMART-PAK Cartridge A and the long end into Cartridge B. **Failure to connect will cause oil to leak inside the cabinet.**
5. Connect the female fitting of the discharge hose on Cartridge A into the male fitting inlet on Cartridge B.
6. Connect the male fitting of the inlet hose on Cartridge A to the female fitting on the inside top of the cabinet.
7. Connect the discharge hose female fitting on Cartridge B to the male fitting on the inside right of the cabinet.
8. Attach the battery-pack wire (zip-tied to inlet hose) to the fitting on the inside top left of the cabinet. **Failure to connect the wire will prevent the unit from operating.**
9. Copy serial numbers from both SMART-PAK Cartridges to use in final step. Reattach front panel.
10. Cut the attached ¾" drain hose on the outside right of the unit to size. Do not allow airlocks, kinks, or excess coil in the drain hose. The hose MUST lay flat or unit will not drain.
11. On top of the unit remove red cap(s), replace it with push-to-lock fitting and connect ¼" condensate line from the compressor.
12. Scan QR code to complete warranty registration.

Questions?

Contact your Distributor or Clean Resources:

- 800-566-0402
- cleanresources.com/contact

- ✓ Check for damage that may have occurred during shipping
- ✓ Avoid damage to couplings
- ✓ Do not over tighten fittings

* When plugging in or unplugging the battery-pack, wait 20 seconds to allow the capacitor to completely charge/discharge.



Re-Order Parts

| Part Number | Description |
|-------------|------------------------------|
| B20041 | OUTLET HOSE ASSEMBLY |
| B21000 | INLET HUB FOR CABINET SYSTEM |
| B24000 | DECOMPRESSION CHAMBER |
| F10410 | CARTRIDGE FOR 300 |
| F10411 | CARTRIDGE FOR 600 |
| F10412 | CARTRIDGES FOR 800 |
| F10413 | CARTRIDGES FOR 1000 |
| F10414 | CARTRIDGES FOR 1500 |

Life Span

| SMART-PAK | CFM | Cartridge Life Span (Months†) |
|-----------|------|-------------------------------|
| 800 | 800 | 12 |
| 1000 | 1000 | 12 |
| 1500 | 1500 | 6 |

† See complete lifespan chart for details:
cleanresources.com/product.html#SMARTseries

**WARRANTY
REGISTRATION**

